




No.	Part Name	QTY	No.	Part Name	QTY
1	M5*20 Screw	4	35	M5*18 Screw	1
3	Exhaust cover	1	36	Trigger piece	1
4	φ18*10*2.6 Rectangular Sealing ring	1	37	M4*14 Screw	4
5	Pressure spring	1	38	Adjusting plate	1
6	φ18.4*2.4 O type sealing ring	1	39	Spring washer 4	6
7	Cylinder cover	1	40	Nailer head cover	1
8	φ41*1.2 O type sealing ring	1	41	M4*6 Screw	4
9	Balanced valve	1	42	Nailer head	1
10	φ36.3*2.5 O type sealing ring	1	43	φ2.5*8 Cylindrical pin	2
11	Flat washer of balanced valve	1	44	φ2.0*10 Elastic cylindrical pin	2
12	Shrink ring	1	45	Plug	1
13	φ27.3*2.5 O type sealing ring	1	47	Label	1
14	Piston subassembly	1	48	Plug spring	1
15	Cylinder	1	49	Settled clip	1
16	Cushion pad	1	50	Movable clip	1
17	Warning label	1	51	Locating base	1
18	φ7.5*3 Rectangular Sealing ring	1	52	M4*8 Screw	2
19	Leather Case	1	53	Torsional spring of positioning hook	1
20	Joint	1	54	Positioning hook	1
21	Flat rubber mat	1	55	Fixed base	1
22	Housing	1			
23	Baffle plate	1	A	Cylinder cover subassembly	
24	M5*20 Screw (nickel-coated knurl)	2	B	Balanced valve assembly	
25	M5 Lock nut	1	C	Cylinder cover assembly	
26	φ12*1.8 Rectangular Sealing ring	1	D	Piston assembly	
27	Valve seat	1	E	Cylinder assembly	
28	φ5.0*1.9 O type sealing ring	1	F	Switch assembly	
29	Pneumatic valve stem	1	G	Trigger piece assembly	
30	φ14*1.9 O type sealing ring	1	H	Housing assembly	
31	Pneumatic valve sleeve	1	I	Fixed base assembly	
32	Spring of trigger piece	1	J	Nailer head assembly	
33	φ5.0*2.0 Rectangular Sealing ring	2	K	Clip assembly	
34	Pin roll	2	L	Accessory bage	