




No.	Part Name	QTY	No.	Part Name	QTY
1	M5*20 Screw	4	34	Pin roll	2
3	Exhaust cover	1	35	M5*18 Screw	1
4	φ18*10*2.6 Rectangular Sealing ring	1	36	Trigger piece	1
5	Pressure spring	1	37	M4*8 Screw	2
6	φ18.4*2.4 O type sealing ring	1	38	Nailer head cover	1
7	Cylinder cover	1	39	M4*14 Screw	2
8	φ41*1.2 O type sealing ring	1	40	Spring washer 4	4
9	Balanced valve	1	41	Nailer head assembly	1
10	φ36.3*2.5 O type sealing ring	1	42	Label	1
11	Flat washer of balanced valve	1	43	Plug	1
12	Shrink ring	1	44	Slug	1
13	φ27.3*2.5 O type sealing ring	1	45	M4*6 Screw	1
14	Piston subassembly	1	46	Plug spring	2
15	Cylinder	1	47	Settled clip	1
16	Cushion pad	1	48	Movable clip	1
17	Warning label	1	49	Plastic cushion block	1
18	φ7.5*3 Rectangular Sealing ring	1	50	Locating base	1
19	Leather Case	1	51	M4*10 Screw	4
20	Joint	1	52	Torsional spring of positioning hook	1
21	Flat rubber mat	1	53	Positioning hook	1
22	Housing	1	54	Fixed base	1
23	Baffle plate	1	A	Cylinder cover subassembly	
24	M5*20 Screw (nickel-coated knurl)	2	B	Balanced valve assembly	
25	M5 Lock nut	1	C	Cylinder cover assembly	
26	φ12*1.8 Rectangular Sealing ring	1	D	Piston assembly	
27	Valve seat	1	E	Cylinder assembly	
28	φ5.0*1.9 O type sealing ring	1	F	Switch assembly	
29	Pneumatic valve stem	1	G	Trigger piece assembly	
30	φ14*1.9 O type sealing ring	1	H	Housing assembly	
31	Pneumatic valve sleeve	1	I	Fixed base assembly	
32	Spring of trigger piece	1	K	Clip assembly	
33	φ5.0*2.0 Rectangular Sealing ring	2	L	Accessory bage	