



## DIAMOND DRILL spare parts list

No.	Part Name	QTY	No.	Part Name	QTY
1	Circlips for hole 12	1	45	Rubber cover	1
2	O Ring $\phi 3 \times 1.5$	3	46	Brush holder	2
3	Water seal	3	47	Carbon Brush	2
4	Side handle pedestal	1	48	Brush cover	2
5	Bearing 6205	2	49	Spring washer 6	4
6	Head shell	1	50	Flat washer 6	4
7	Bearing 6204	1	51	M6*50 Screw	4
8	Output shaft	1	52	Thermal protector 8A	1
9	Flat key 5*5*16	1	53	Switch	1
10	Gear	1	54	Left handle	1
11	Circlips for shaft 20	1	55	ST5*22 Screw	4
12	Roundwire snap rings for hole 12	1	56	ST4*18 Screw	3
13	Water pipe	1	57	ST4*14 Screw	2
14	O Ring $\phi 6 \times 1.5$	1	58	Cord clamp	1
15	Bearing 609	2	59	Right handle	1
16	Flat key 5*5*12	1	60	Sheath	1
17	Secondary gear shaft	1	61	Cabel	1
18	Gear Bushing	1	62	Circlips for shaft 14	1
19	Friction plate pressplate	2	63	Screw M6*25	2
20	Friction plate	2	64	Screw M6	2
21	Secondary gear	1	65	Lifting body	1
22	Calathiform washer	1	66	Screw	1
23	Locknut	1	67	Plug	1
24	Middle cover	1	68	Lifting cover	1
25	M6*15 Screw	1	69	Screw M6*20	5
26	Elbow	1	70	Screw M8*30	4
27	O Ring $\phi 8 \times 1.5$	1	71	Screw M8	4
28	Faucet	1	72	Handgrip	1
29	Rubber column $\phi 5 \times 8$	1	73	Screw M6*30	2
30	Bearing 6003	1	74	Ball knob	1
31	Washer	1	75	Control lever	1
32	Armature	1	76	Lock washer	4
33	Creepage shield ring	1	77	Big liner	3
34	Bearing 6200	1	78	Small liner	4
35	Wave pad 30	1	79	Bearing 6002	2
36	Wind baffle	1	80	Lifting gear shaft	1
37	ST5*70 Screw	2	81	Circlips for shaft 15	2
38	Assist handle	1	82	Sleeve	1
39	Field Coil	1	83	Bolt M12*60	2
40	Motoe housing	1	84	Nut M12	2
41	Rear cover	1	85	Pedestal	1
42	ST4*16 Screw	2	86	Upright	1
43	Rear support	1	87	Bolt M10*55	2
44	ST4*26 Screw	4			