




ELECTRIC DRILL spare parts list

No.	Part Name	QTY	No.	Part Name	QTY
1	Screw	1	19	Brush holder	2
2	Chuck	1	20	Carbon brush	2
3	Spindle	1	22	Screw	2
4	Semi key	1	23	Wind ring	1
5	Circlip	1	24	Stotor	1
6	Ball bearing 6002	1	25	housing	1
7	Circlip	1	26	Lable	1
8	Screw	2	27	Lable	1
9	Screw	1	28	Switch	1
10	Gear box	1	30	Tension disc	1
11	Big gear	1	31	Screw	2
12	Circlip	1	32	Cord guard	1
13	Ball bearing 698	1	33	Male tab	4
14	Middle cover	1	34	Outgoing line	2
15	Ball bearing 609	1	37	Screw	7
16	Rotor	1	38	Cable plug	1
17	Ball bearing 607	1	501	Side handle	1
18	Bearing sleeve	1			